Protocol Definition

September 25, 2016

Contents

| 1 | Overview 1 | | | | |
|---|------------|--------|------------------------|---|--|
| | 1.1 | Client | Actions | 1 | |
| | 1.2 | Server | Actions | 2 | |
| 2 | Web | Socke | et Protocol Definition | 2 | |
| | 2.1 | Client | Actions | 2 | |
| | | 2.1.1 | Message Actions | 2 | |
| | | 2.1.2 | Channel Actions | 2 | |
| | | 2.1.3 | User Actions | 3 | |
| | 2.2 | Server | Actions | 3 | |
| | | 2.2.1 | Message Actions | 3 | |
| | | 2.2.2 | Channel Actions | 4 | |
| | | 2.2.3 | USER Actions | 5 | |
| | | 2.2.4 | ERROR | 5 | |

1 Overview

1.1 Client Actions

```
Clients will send messages to the server in the following format: \{
```

```
"command": "COMMANDNAME",
"args": ["arg1", "arg2"]
}
```

1.2 Server Actions

```
Clients will receive messages from the server in the following format:

{
    "user": "username",
    "command": "COMMANDNAME",
    "args": ["arg1", "arg2"],
```

"timestamp": 1326439500 // Unix Timestamp

```
2 WebSocket Protocol Definition
```

2.1 Client Actions

}

2.1.1 Message Actions

2.1.2 Channel Actions

```
1. JOIN - Join Channel
    {
        "command": "JOIN",
        "args": ["channel1", "channel2"] // any number of channels
}
```

2. PART - Leave Channel

```
{
         "command": "PART",
         "args": ["channel1", "channel2"]
  3. INVITE - Invite User to Channel
         "command": "INVITE",
         "args": ["channel", "user1", "user2"] // any number of users
    }
  4. CHANLIST - List Channels on Server
         "command": "CHANLIST",
         "args": []
    }
2.1.3 User Actions
  1. USER - Set Username
    {
         "command": "USER",
         "args": ["username"]
    }
  2. USERLIST - List Users on Server
         "command": "USERLIST",
         "args": []
```

2.2 Server Actions

2.2.1 Message Actions

1. MSG - Receive Message From a Channel

```
"user": "username",
         "command": "MSG",
        "args": ["channel", "message text goes here"]
        "timestamp": 1326439500 // Unix Timestamp
  2. PRIVMSG - Receive Message From User
         "user": "username",
         "command": "PRIVMSG",
         "args" ["user", "message text"]
         "timestamp": 1326439500 // unix timestamp
    }
2.2.2 Channel Actions
  1. JOIN - Someone Joined the Channel
        "user": "anthony",
        "command": "JOIN",
         "args": ["channel1"]
         "timestamp": 1326439500 // Unix Timestamp
    }
  2. PART - Someone Left the Channel
    {
         "user": "username",
         "command": "PART",
         "args": ["channel"]
         "timestamp": 1326439500 // Unix Timestamp
    }
  3. CHANLIST - Enumerate Channels on Server
        "user": "",
        "command": "CHANLIST",
        "args": ["chan1", "chan2"] // all channels on server
```

```
"timestamp": 1326439500 // Unix Timestamp
}

2.2.3 USER Actions

{
    "user": "",
    "command": "USERLIST",
    "args": ["user1", "user2"] // all users on server
    "timestamp": 1326439500 // Unix Timestamp
}

2.2.4 ERROR

{
    "command": "ERROR",
    "args": ["error text"]
}
```